





Instruction Manual

The WEL-200 is a complete wireless solution for interfacing sensing edges to gate and door operators, while ensuring compliance with UL325 monitoring standards. **The WEL-200 Transmitter (per page 5, step 6) requires the edge (sold separately) to have a built-in resistor with a value between 4K – 12K ohms. Non-resistive edges DO NOT work with this system.** Each receiver can connect with up to four transmitters with separate relay and pulse outputs for open and close edge functionality. Each transmitter can run for up to two years on two AA lithium batteries. With enhanced diagnostic features, installation and maintenance for the WEL-200 is easy and reliable. Feedback is provided for all fault modes, including edge open, short conditions, low battery and failed transmitters.




DON'T SHOCK ME!

WEL-200T components are sensitive to static shocks (ESD)




1. Ground yourself by touching a metal object
2. Hold the circuit board only by the edges

Included Parts



WEL-200TX



Bracket



**Flanged Hex
Head Drilling
Screw**



2x AA Batteries

Specifications

	Receiver (WEL-200R)	Transmitter (WEL-200T)
Operating Range	200 ft (line of sight)	
Operating Frequency	915 MHz (25 possible channels)	
Response Time	100 ms	
Operating Temperature	-40° to 140°F (-40 to 60°C)	
Power	12-24 VDC/AC	2 AA lithium batteries ~ 2-year life
Current Draw	1 Relay – 42mA, 2 Relay – 70mA	N/A
Surge Protection	Thermal fuse, MOV	Thermal fuse
Outputs	300 Hz pulsed, or relay with selectable 10K ohm resistor across normally open contact	N/A
Edge Resistance Range	–	4K – 12K Ohms
Dimensions	5.5" (140 mm) x 1.3" (34 mm) x 3.5" (90 mm)	7" (180 mm) x 1.3" (32 mm) x 2.6" (67 mm)
Connections	12 terminals	2 terminals

Ordering Information

- WEL-200K Wireless edge link kit, includes WEL-200R, WEL-200T, 2 cable grip inserts and 2 AA lithium batteries
- WEL-200R Wireless edge link receiver
- WEL-200T Wireless edge link transmitter

Receiver Connections

1. Channel Assignment Button

2. Channel Status LEDs

- Off when connected to transmitter with edge sensor
- On when connected to transmitter with shorted edge sensor
- Flashes in sync with system LED when no transmitter is connected to channel
- Flashes 2x faster than the system LED when a paired transmitter is no longer communicating
- Flashes twice quickly with one second off when a connected transmitter has an open edge sensor.

3. RADIO

4. DIP SWITCH

- Assigns each channel to Relay1 or Relay2
- Enables or Disables 10K

5. POWER LED

- RED when power is on

6. SYSTEM STATUS LED

- Flashing green when operating correctly

7. TERMINAL BLOCK

8. EARTH GROUND


9. Signal Quality Tx Select

- Selects which transmitter's signal quality is shown

10. Signal Quality Display

- Show the RF signal strength for the currently selected transmitter.
- Battery life may be impacted when signal is below "4"

WEL-200 Receiver



Terminal	Description
PULSE 1 COM	Pulse common connection for channels assigned to Relay 1 on DIP switch
PULSE 1 OUT	Pulse output for channels assigned to Relay 1 (300/0 Hz)
PULSE 2 COM	Pulse common connection for channels assigned to Relay 2 on DIP switch
PULSE 2 OUT	Pulse output for channels assigned to Relay 2 (300/0 Hz)
RELAY 1 NC	Normally closed relay connection for channel assigned to Relay 1 on DIP switch
RELAY 1 COM	Common relay connection for channels assigned to Relay 1
RELAY 1 NO	Normally open relay connection for channels assigned to Relay 1
RELAY 2 NC	Normally closed relay connection for channel assigned to Relay 2 on DIP switch
RELAY 2 COM	Common relay connection for channels assigned to Relay 2
RELAY 2 NO	Normally open relay connection for channels assigned to Relay 2
POWER	12-24 VDC/AC power input (non-polarized)
EARTH	Earth ground connection (not required)

Radio Signal Quality Display

1. The WEL-200 Receiver has a one-digit display in the top left corner of the PCB that will report a scaled signal quality for the currently selected transmitter. This tool can be used to ensure the devices are operating with sufficient signal.

Failing to achieve good signal quality may cause the setup to experience periodic disconnections, or lower total battery life due to transmitter taking extra attempts at sending edge data to the Rx.

The connection strength indicator can show between (9) and (0) with (9) being the best signal possible, and a 0 being the worst signal possible.



Signal Quality Value	Connection Status	Possible Issues
9 thru 5	Good Connection	-
4 thru 1	Poor Connection	Reduced Battery Life due to Packet Loss
0	Very Poor Connection	Reduced Battery life and TX may periodically disconnect
Blank w/ Decimal Point	Disconnected Transmitter	Receiver relay will activate causing gate to stop

TIP:

Once a transmitter is connected, the signal quality display will update once every 4 seconds. During installation, this update rate can be speed up to update twice per seconds by shorting the edge input on the transmitter. This makes the display much more responsive when testing possible mounting locations.

LED Indicators Explained




TRANSMITTER	RECEIVER	System State	Cause
Status LEDs	Green channel LED		
G R Y Yellow ON Solid	 One Second ON One Second OFF	Transmitter is not Paired	The transmitter hasn't been paired to a receiver
G R Y One Green Blink	(OFF)	Paired and Edge Good	Normal Operation when paired and edge isn't compressed
G R Y Constant Green Blinks	 ON Solid	Paired and Edge Shorted	The edge is compressed, or the edge input is shorted
G R Y One Blink on Green and Yellow LEDs	 Two Blinks	ERROR: Paired and Edge Open or Incorrect Edge	The edge connected to the input is the wrong type, or the edge cable is broken or disconnected
G R Y Three Red Blinks	 Three Blinks	ERROR: Low Battery	Transmitter Battery Voltage is below 2.7V. Replace the batteries
G R Y Long Blink on Green and Yellow LEDs	 Two Blinks Per Second	ERROR: Paired and Lost Connection to Rx and edge is also open or wrong edge	Connection to the Receiver is very poor or disconnected. Transmitter flash pattern may indicate the paired receiver is powered off.
G R Y Green Long Blink	 Two Blinks Per Second	ERROR: Paired and Lost Connection to Rx and edge is good	Connection to the Receiver is very poor or disconnected. Transmitter flash pattern may indicate the paired receiver is powered off.
G R Y (OFF)	 Two Blinks Per Second	ERROR: Transmitter Batteries Dead	The transmitter's batteries are completely drained and it has disconnected from the receiver.
G R Y Alternating Red - Green	 Two Blinks Per Second	ERROR: Hardware Failure	Hardware has failed on this channel's transmitter. Replace the transmitter.

Configuration DIP Switch

- The DIP Switch located in the upper middle section of the board is used to assign transmitters to a particular relay and to enable/disable the 10k resistor on both Relay1 and Relay2.

For example, If DIP Switch position 1, 5, 6 are ON, and position 2, 3, 4 are OFF Tx1 will output to Relay1/Pulse1, Tx2, Tx3, and Tx4 will output to Relay2/Pulse2 Both Relay1 and Relay2 will have the 10K enabled across NO and COM.



Dip Switch Position	Function	
1	Relay Assignment, Transmitter #1	ON(UP) = Relay1, OFF(Down) = Relay2
2	Relay Assignment, Transmitter #2	ON(UP) = Relay1, OFF(Down) = Relay2
3	Relay Assignment, Transmitter #3	ON(UP) = Relay1, OFF(Down) = Relay2
4	Relay Assignment, Transmitter #4	ON(UP) = Relay1, OFF(Down) = Relay2
5	10K Enable for Relay 1	ON(UP) = 10K enabled, OFF(Down) = 10K disabled
6	10K Enable for Relay 2	ON(UP) = 10K enabled, OFF(Down) = 10K disabled

Installation

Connecting the Receiver

- Mount the receiver to the exterior of the operator using four #8 machine screws, washers, lock washers and nuts. Open the cover to expose the mounting holes. Place the receiver in direct line of sight with all edge transmitters. Mount the receiver with the sealing nut facing down to prevent water from entering the housing. Refer to the WEL-200 QuickStart guide for detailed mounting instructions.




TIP:

Extend the top of the receiver approximately 1" above the top edge of the operator housing, or on the side that is in line of sight of all transmitters.


- Pass the operator wires through the sealing nut, cable grip, and body into the receiver housing.

TIP:

- Cables for the original cable grip insert must be 0.181-0.321" (4.6-7.9 mm) in diameter to maintain a proper watertight seal.
- For smaller cables, replace the original cable grip insert with a white insert by removing it from inside the body.
- To maintain a watertight seal, 1.) only use round cables 2.) mount the receiver with the sealing nut facing down



- Connect the operator wires to the terminal block, per one of the monitoring methods below and according to the instructions provided by the operator manufacturer. **Connect power wires last.**




Pulse Monitoring

- For channels assigned to Relay 1, connect the operator common to terminal 1 and operator input to terminal 2.
- For channels assigned to Relay 2, connect the operator common to terminal 3 and operator input to terminal 4.


10K or Normally Closed Monitoring

- For channels assigned to Relay 1, connect the operator common to terminal 6, and the operator input to terminal 5 or 7.
- For channels assigned Relay 2, connect the operator common to terminal 9, and the operator input to terminal 8 or 10.
- For **10K** resistive monitoring, place the 10K DIP switch into the "ON" position. Position 5 is for Relay1, and Position 6 is for Relay2
- For Non-Monitored or NC installations, put the 10k DIP switch into the "OFF" position.

10k DIP Switches



4. On the DIP switch, indicate which transmitter channels will output through Relay 1 and Relay 2 terminals by setting the corresponding DIP. For example, the image to the right shows Tx1 outputting through Relay1, and Tx2,3 and 4 outputting through Relay2.



Connecting the Transmitter

5. Mount the transmitter bracket near the edge sensor using two screws. The larger flange should be facing down, or to the side.

6. Connect the resistor equipped edge sensor wires to the transmitter terminal block (3 on image) after passing them through the cable grip. Insert batteries. The yellow LED (#2 on image) will turn ON solid, indicating the device is unpaired.

TIP:

- **Never connect more than one edge sensor to a single transmitter.**
- **The edge sensor must have a resistance between 4K – 12K ohms.**
- **A RED LED flashing three times per second indicates that the batteries are low (less than 2.7 V) and need to be replaced.**

7. After powering the receiver, the system status LED will flash rapidly while it is finding a clean operating frequency (this can last several seconds). Once completed, the system status LED will flash on/off every 2 seconds. Initialization is now complete.

TIP:

To perform a factory reset of the receiver, press 1 and 4 channel assignment buttons simultaneously until the status LED flashes quickly. This will clear all connected channels and reset the system.

8. To enter channel assignment mode, on the receiver, hold down the desired channel assignment button until the systems status LED begins flashing rapidly, then release the button.

To exit channel assignment mode, wait 120 seconds or cycle power to the receiver.

WEL-200 Transmitter



9. On the transmitter, press and hold down the pairing button (4 on image above) for 1 - 2 seconds until the yellow LED turns off. Upon successful connection, the green and yellow LED will begin showing the current system state. Refer to page 4 for more information on LED flashes. If the transmitter fails to connect, it will return to its initial state, with the yellow LED on solid. If this occurs, repeat this step. If the transmitter continues to fail to connect, proceed to the troubleshooting section.

TIP:

To remove a connection from the transmitter, hold down the pairing button. The green LED will turn on solid for several seconds, and then the yellow LED will turn on solid when disconnected.

10. Test the connection. Without activating the edge sensor, observe the channel LEDs on the receiver. They should be off for any channel connected to a transmitter. Activate the edge sensor being tested. On the receiver, the channel LED for the tested edge's channel should turn on. On the transmitter, the green LED should flash twice every second while the edge sensor is activated. If the channel does not exhibit this behavior, double check the edge sensor wiring, termination, and transmitter batteries.
11. Close the transmitter housing using the four screws on the back cover. Then mount the closed transmitter to the bracket, the sealing nut should be facing down, or to the side to prevent water ingress.
12. Repeat steps 5 through 10 for each additional transmitter. Never connect more than one edge sensor to a single transmitter.


WEL-200 Compatibility (Red, Black, and Green Boards)

1. New WEL-200 systems (Red Boards) will not be compatible with older receivers and transmitters (Green Boards). This is because of an upgrade to the communication protocol as well as other advancements in the system's ability to find clean RF channels.
2. Using the color of the boards is the best way to determine compatibility.
- Transmitters with a **GREEN PCB** must be used with a receiver that also has a **GREEN PCB**.
 - Transmitters with a **RED PCB** must be used with a receiver that also has a **RED OR BLACK PCB**.
 - Transmitters with a **Black PCB(New Housing)** must be used with a receiver that has a **RED/BLACK PCB**.


Transmitter and Bracket



**Use two screws to mount
bracket to Post**



**Use the single screw at the top to secure
plastic housing to the bracket**



**Angle the
housing into the
slot at bottom of
bracket**

Troubleshooting

Symptom	Possible cause	Solution
Receiver channel LED is on, regardless of edge sensor state	Edge sensor's resistance is too low. Edge wires are shorted	1. Disconnect edge sensor from transmitter. 2. Connect a digital multimeter to the edge leads and set to read ohms. The meter should read between 4K and 12K. 3. If the meter reads outside of this range the edge sensor is defective. Replace the edge sensor.
Receiver channel LED flashes 2x then pauses every second. Transmitters yellow and green LED blink together every 4s.	Edge sensor resistance above 12K Improper connection to edge sensor Damaged wires	1. Disconnect edge sensor from transmitter. 2. Connect a digital multimeter to the edge leads and set to read ohms. The meter should read between 4K and 12K. If the meter reads outside this range the edge sensor is defective. Replace edge sensor. 3. Press on the edge sensor and confirm resistance drops to zero.
Receiver channel LED flashes once per second	Transmitter not connected to receiver	Repeat step 9 in transmitter installation

Receiver channel LED flashes 0.5 seconds on, 0.5 seconds off	Poor signal Strength Completely dead batteries	Ensure Receiver and Transmitter have line of sight throughout gate open/close operation. If new AA lithium batteries are installed in transmitter and the transmitter LED does not light, then replace transmitter. To perform a RF Channel hop, press 2 and 3 channel assignment buttons simultaneously.
Receiver channel LED flashes 3x per second or transmitter RED LED flashes 3 times.	Transmitter batteries are low (less than 2.7V)	Replace batteries with two AA lithium batteries 1.5V

Warranty

EMX Industries, Inc. products have a warranty against defects in materials and workmanship for a period of two years from date of sale to our customer.